

0102

BITTER[®] FIT TEST KIT

FIT TEST RESPIRATOR WEARERS

Test the face to facepiece seal of Moldex particulate respirators. Check that respirators are being worn correctly and that they fit satisfactorily. Ensure that users are properly protected.

EASY TO USE

The Moldex Fit Test Kit contains everything needed to conduct a qualitative fit test. Written instructions provide easy-to-use, step-by-step instructions. It's a simple pass/fail test. Taste sensitivity to Bitter is checked. The wearer dons a Moldex particulate respirator, the fit test hood is put on and the fit test solution is sprayed into the hood.



APPROVED FIT TEST METHOD

OSHA requires that a user be fit tested before wearing a respirator. The Moldex Bitter Fit Test Kit can help you meet respirator program fit test requirements established by OSHA 1910.134.

FEATURES

- Includes everything necessary to conduct a Bitter Qualitative Fit Test
- Easy-to-follow, step-by-step instructions
- Helps satisfy OSHA respirator program requirements

0102

BITTER FIT TEST KIT

0102 BITTER QUALITATIVE FIT TEST KIT

- 0201 Fit Test Hood (1)
- 0301 Nebulizer #1 (Threshold Screening for Taste Sensitivity)
- 0302 Nebulizer #2 (Fit Test)
- 0503 Sensitivity Screening Solution (2.5 mL per Ampule)
- 0504 Fit Test Solution (2.5 mL per Ampule)
- 0702 Qualitative Fit Test Instructions

NOTES:

1. Use with any Moldex N, R or P class disposable respirator. This fit test kit may also be used with any Moldex half mask respirator by using any N R or P class filter.
2. You should get approximately 3 – 5 fit tests per applicator tube (fit test cycle) or 18 – 30 per supply of Bitter solution in this kit.
(Reorder #0503 & #0504)

WARNING TO USER

1. Before use, the user must first be trained by the employer in proper respirator use, in accordance with applicable safety and health standards, for the contaminant and exposure level in the assigned work area.
2. The particulates and other contaminants which can be dangerous to your health include those which you cannot see, taste, or smell.

LIMITED WARRANTY IMPORTANT NOTICE TO PURCHASER

This limited warranty is made in lieu of the warranties of merchantability, fitness for particular purposes and all other warranties, express or implied. There are no other warranties which extend beyond the description on the face hereof. The physical standards and specifications of Moldex will be met by products sold. Exclusive Remedies: damages for the breach of this limited warranty are limited to the replacement of such quantity of Moldex, products proved to be defectively manufactured. Except as provided above, Moldex shall not be liable or responsible for any loss, damage, or liability, direct, indirect, incidental, special, or consequential, arising out of sale, use, or misuse, or the inability to use products by the user.

MOLDEX TECHNICAL ASSISTANCE

For more information call +1 (800) 421-0668 or +1 (310) 837-6500 ext. 512 or E-mail: tech@moldex.com or visit www.moldex.com.

DISTRIBUTED BY:



MOLDEX[®]
Ideas that wear well.

MOLDEX-METRIC, INC.
10111 Jefferson Blvd.
Culver City, CA 90232
TEL: +1 (800) 421-0668 or
+1 (310) 837-6500
FAX: +1 (310) 837-9563
E-mail: sales@moldex.com
www.moldex.com

CANADIAN CUSTOMER SERVICE
Tel: +1 (800) 421-0668, Ext. 550/512
Fax: +1 (310) 837-9563



Printed on Recycled Paper